



ON/OFF: peut être utilisé avec ou sans alarme.

SANS ALARME: abaisser la serrure 1 seule fois.

AVEC ALARME: abaisser 2 fois la serrure dans un intervalle de 8 sec.; 1 bip d'activation sonnera. Après 8 sec. 2 bips sonneront confirmant que le capteur est en situation d'alerte. Lorsque l'alarme est déclenchée, après 15 sec. sans avoir détecté une autre attaque, le capteur retourne à son état d'alerte.

ON/OFF: lo puedes usar con o sin alarma.

SIN ALARMA: bajar la cerradura 1 vez. **CON**

ALARMA: bajar 2 veces la cerradura en un intervalo de 8 seg, sonara 1 bip de activación. Pasados 8 seg. mas sonarán 2 bips confirmando que el sensor está en alerta. Cuando se dispara la alarma, pasados 15 seg. sin detectar otro ataque, el sensor vuelve al estado de alerta.

ON/OFF: Can be used with or without alarm.

WITHOUT ALARM: moving down the lock cylinder 1 time. **WITH ALARM:** Moving down the lock cylinder twice in 8 sec., 1 activation beep will sound. After 8 sec. 2 beeps will sound confirming that the sensor is on alert. When the alarm is triggered, after 15 sec. without detecting another attack, the sensor returns to the alert state.

